

Adjustment

Step 1

Slightly tighten post screw.



Step 2

Hold snips open at 90 degrees. Allow the horizontal blade to drop. The best adjustment will leave the tips open 1/8" to 1/4" after drop. If opening is less than 1/8", repeat steps 1 and 2.



Step 3

After drop test, turn snips over with post screw head facing downward. Support snips on a wooden block. Peen the tip of the post screw lightly to prevent screw backing out.



Sharpening

Hold snips in one hand and brace front tip of blade firmly on table or bench top. Using a Mill Bastard File, file on forward stroke 4-5 times, maintaining original surface angle (30 degrees). File only the non-serrated blade.

As an alternative, the Jameson Scissors and Knife Sharpener is recommended.



The use of a mechanical grinder is not recommended.

Handle Adjustment

After prolonged use or extensive sharpening, a gap may persist between tips. Hold handle shank firmly with arch facing upward (as shown). Lightly tap arch with a hammer. Repeat this procedure on opposite shank if necessary. Continue this procedure until proper alignment is achieved.





Part #32-40



1. Align Snip Grip® handle sections on Scissors.
2. Secure Snip Grip® on Scissors with two 6/32" X 1/4" screws (included), using Phillips screwdriver.
3. Tighten screws until Snip Grip® edges fit evenly and snugly on scissors. Do not overtighten.

