




Fast, Efficient Ground Rod Installation

- Quickly install ground rods with rotary hammer
- Driver slides over rod end, positions at any height
- Safely install rods from ground level
- No rod damage, easily connect ground clamps

Ground Rod Driver does not include drive socket or rotary hammer.

Designed for use with rotary hammer. Use of impact tools or jack hammer may shorten service life.



Ground Rod Drivers

| | |
|--------|---|
| RD0012 | Ground Rod Driver - 1/2" Rod Dia. (Blue) |
| RD0058 | Ground Rod Driver - 5/8" Rod Dia. (Red) |
| RD0034 | Ground Rod Driver - 3/4" Rod Dia. (Green) |
| RDSK | Driver Socket (SDS-Max Shank) |

